




BLENDER

INSTRUCTION MANUAL



MODEL: RM/391

Read this manual thoroughly before using and save it for future reference

IMPORTANT SAFEGUARDS

When using electrical appliance. Basic safety precautions should always be followed including the following:


1. Read all instructions.
2. Before using check that the voltage power corresponds to the one shown on the appliance nameplate.
3. Do not let cord hang over edge of table or counter.
4. Do not operate any appliance with a damage cord or plug or after the appliance malfunction or has been damaged in any manner. Return the appliance to the nearest authorized service facility for examination, repair or adjustment.
5. If the supply cord is damaged, it must be replaced by the manufacture or its service agent or a similarly quality person in order to avoid a hazard .
6. Close supervision is necessary when any appliance is used by or near children.
7. Avoid contacting moving parts.
8. Blades are sharp, so handle carefully.
9. Never use hot liquids or run the appliance empty.
10. The use of accessory not recommended or sold by the manufacturer may cause fire, electric shock or injury.
11. The appliance can not be used for blending or chopping hard and dry substance, otherwise the blade could be blunted. But it can be used for blending ice cube.
12. Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
13. To protect against risk of electrical shock do not put unit in water or other liquid.
14. Be sure blending cover are accurately put in place before operating appliance
15. Keep hands and utensils out of container while blending to reduce the risk of severe injury to persons or damage to the blender. A scraper may be used but must be used only when the blender is not running.
16. To reduce the risk of injury, never place cutter-assembly blades on base without jar or bowl properly attached.
17. The appliance is not intended to be operated by means of an external timer or separate remote-control system.
18. This appliance is not intended for used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliances by a person

responsible for their safety.

19. Children should be supervised to ensure that they do not play with the appliance.
20. Do not immerse the Motor Unit into water or other liquids.
21. Crushing ice or blending viscous food at the highest speed.
22. Do not use outdoors.
23. Save these instructions.

HOUSEHOLD USE ONLY

KNOW YOUR BLENDER



BEFORE THE FIRST USE

Check that all parts are complete and not damaged. Choose the appropriate attachment to perform your desired task. The blender attachment is suitable for blending fruits or vegetables or crushing ice, while the coffee grinder attachment for grinding coffee.while the grinder attachment for grinding the cayennes or garlics. Clean the attachment according to the section “**CLEANING AND MAINTENANCE**”.

WARNING: The blade is sharp, handle with great care and ensure that unplug the appliance from outlet before assembling and removing parts.

BLENDER OPERATIO

1. Lay the motor unit on the flat horizontal surface and make sure it is unplugged.
2. Place the Jar on the **Motor Unit**, let the triangle almost align with the word “**UNLOCK**” on jar base and then turn the jar clockwise until the triangle aligns with the word “**LOCK**”, a click will be heard when locked into position properly. Please see Fig.1.




Fig. 1

NOTE: There is a safety interlock device at the bottom of jar, if the jar is not assembled in place, the blender will not operate.

3. Open the jar cover by turning anticlockwise and place it on the surface. Peel or core the fruits or vegetables and then cut it into small pieces. Peel or core the fruits or vegetables and then cut it into small pieces, then put them into the jar. Usually certain amount of purified water has to be added to facilitate the smooth running of appliance. The amount of mixture should not exceed the max level as indicated on the jar, nor sit lower the min level. The best proportion of the fruits or vegetables and water is 2:3. **When blending light liquids do not fill above the 1250ml mark indicated on the blender jug to avoid overspill from the jug brim.**

NOTE: The blender is not applicable for beating egg white, mashing potatoes, mixing dough, extracting juice from fruit and vegetable.

4. Replace jar cover on the jar and turn it by clockwise.

NOTE: There is a safety interlock device at the side of jar cover, if the jar cover is not assembled in place, the blender will not operate.

- 5. You may add ingredient into the jar through the center opening of jar cover during operation, then replace measuring cup if necessary. Let the tabs of measuring cup aligns with the grooves of jar cover, put down and turn the measuring cup by anti-clockwise until it in place.
- 6. Ensure the **Speed Selector** to “0” Position, then plug into power outlet and set **Speed Selector** to your desired setting. You can set **Speed Selector** to the “M” position if want to accelerate the process of blending. The detailed information is shown in below fig. 2

NOTE: Make sure the jar cover is placed in position completely before operating, and never open the jar cover during operation.




Fig. 2

- 7. Do not operate for more than 3 minutes per time, at least 10 minutes rest time must be maintained between two continuous cycles, let the unit cool to room temperature before performing next operation cycle.

8. Turn the **Speed Selector** to “0” Position once the mixture has been blended to your desired consistency.
9. Turn the jar by anti-clockwise and remove it from the motor unit, carefully take down the jar cover, then pour and serve.

COFFEE GRINDER OPERATION

1. Lay the motor unit on the flat horizontal surface and make sure it is unplugged.
2. Fill the grinding bowl with proper coffee bean, then assemble the grinding blade assembly and grinding bowl together. Please see Fig.6

NOTE: The quantity of coffee bean the grinding bowl allows to grind is Max 60g.

3. Place the grinder attachment on the motor unit, let the triangle almost aligns with the word “UNLOCK” on bowl base then turn the bowl clockwise until the triangle aligns with the word “LOCK”, a click will be heard when locked into position properly. Please see Fig. 7

NOTE: There is a safety interlock device at the bottom of bowl, if the bowl is not assembled in place, the grinder will not operate.

4. Ensure the **Speed Selector** to “0” Position, then plug into power outlet.
5. Select the desired speed setting, the appliance will start grinding. During grinding, you can tweak the **Pulse button** without releasing it if you want to accelerate the process of grinding.
6. Turn the **Speed Selector** to “0” Position once the coffee has been ground to your desired result.
7. Disconnect from power supply once finished. Disassemble the grinder attachment from the unit, keep the grinding bowl downward and turn it by anticlockwise (see fig.8), then empty the bowl and serve.
8. Do not run the appliance for more than 1 minutes per time, at least 10 minutes rest time must be maintained between two continuous cycles, let the unit cool to room temperature before performing next operation cycle.



Fig. 6




Fig. 7




Fig. 8

GRINDER OPERATION

9. Lay the motor unit on the flat horizontal surface and make sure it is unplugged.
10. Fill the grinding bowl with proper cayennes or garlics, then assemble the grinding blade assembly and grinding bowl together. Please see Fig.6

NOTE: The quantity of cayennes or garlics the grinding bowl allows to grind is Max 60g.

11. Place the grinder attachment on the motor unit, let the triangle almost aligns with the word “UNLOCK” on bowl base then turn the bowl clockwise until the triangle aligns with the word “LOCK”, a click will be heard when locked into position properly. Please see Fig. 7

NOTE: There is a safety interlock device at the bottom of bowl, if the bowl is not assembled in place, the grinder will not operate.

12. Ensure the **Speed Selector** to “0” Position, then plug into power outlet.
13. Select the desired speed setting, the appliance will start grinding. During grinding, you can tweak the **M** without releasing it if want to accelerate the process of grinding.
14. Turn the **Speed Selector** to “0” Position once the coffee has been ground to your desired result.
15. Disconnect from power supply once finished. Disassemble the grinder attachment from the unit, keep the grinding bowl downward and turn it by anticlockwise (see fig.8), then empty the bowl and serve.
16. Do not run the appliance for more than 1 minutes per time, at least 10 minutes rest time must be maintained between two continuous cycles, let the unit cool to room temperature before performing next operation cycle.



Fig. 6




Fig. 7




Fig. 8

WARNING:

1. Never operate the appliance continuously for more than 3 minutes per time.
2. Blades are very sharp. Handle with care.
3. Do not operate without the jar or bowl cover in place.
4. Do not disassemble the jar or bowl from the jar base or bowl base in general condition.

CLEANING AND MAINTENANCE

Make sure to disconnect appliance from power supply before cleaning

For blender

The Auto Clean function can clean the blender easily and rapidly in complete safety.

1. Pour a little warm soapy water into the Jar and turn the **Speed Selector** to “**M**” position for a few seconds.
2. Remove the Jar and rinse under running water.
3. Dismantle all detachable parts. Disassemble the Jar from the motor unit and rinse it under running water, then detach the blade assembly from the jar assembly, take the blade assembly out, finally remove the jar base seal ring (see fig.6). In addition, detach the measure cup from the jar cover. Rinse the jar, blade, jar base, jar cover and measure cup under running water.




Fig.6

4. Wipe the outer surface of motor unit with a damp cloth

NOTE: Do not use abrasive cleanser and never immerse it in water for cleaning

5. Dry all parts and then assemble them. The method of assembling blender attachment just is in opposite of its detaching sequence.

NOTE: If any problem has been encountered during using, never disassemble the Motor Unit by yourself. There are no user serviceable parts inside. Only contact the authorized service facility for examination and repair.

For grinder or coffee grinder

1. Detach the bowl base from the grinding blade assembly.

NOTE: While detaching, only grasp the unsharp part of grinding blade or wear glove to prevent any injuries.

2. Immerse the blade, bowl base and grinding bowl into warm soapy water for cleaning, and then rinse them under running water.

3. Wipe the outer surface with damp cloth.

NOTE: Never immerse the motor unit into water for cleaning.

4. Dry all parts thoroughly and assemble them in position.

ENVIRONMENT FRIENDLY DISPOSAL



You can help protect the environment!

Please remember to respect the local regulations: hand in the non-working electrical equipments to an appropriate waste disposal centre.

