


WATER DISPENSER

USER MANUAL

Model: RM/559
RM/561



Please read the manual carefully before operating your water dispenser. Retain it for future reference.

DIRECTORY

A.SAFETY INSTRUCTION	1
B. FUNCTION INTRODUCTION.....	1
C. PART NAME	2
D. OPERATION INSTRUCTION.....	3
E. CAUTION.....	3
F.TROUBLE SHOOTING.....	5
G. CLEANING	5
H. MACHINE INSTALLATION	6

The packaging material used is recyclable; we recommend that you separate plastic, paper and cardboard and give them to recycling companies. To help preserve the environment, the refrigerant used in this product is R134a (Hydrofluorocarbon -HFC), which does not affect the ozone layer and has little impact on the greenhouse effect. According to WEEE (Waste of Electrical and Electronic Equipment) guidelines, waste from electrical and electronic devices should be collected separately. If you need to dispose of this appliance in the future, do NOT throw it away with the rest of your domestic garbage. Instead, please take the appliance to the nearest WEEE collection point, where available.




A.SAFETY INSTRUCTION

1. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
2. Children should be supervised to ensure that they do not play with the appliance.
3. This appliance is intended to be used in household and similar applications such as: staff kitchen areas in shops, offices and other working environments; farm houses and by clients in hotels, motels and other residential type environments; bed and breakfast type environments; catering and similar non-retail applications.
4. The appliance must not be cleaned by a water jet.
5. The appliance is suitable for indoor use only.
6. WARNING: Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
7. WARNING: Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
8. The appliance must not be immersed.
9. This product is not recommended at an altitude of 2500 meters above the region to use.
10. Rated voltage: 220-240V/50/60Hz.
11. WARNING: When positioning the appliance, ensure the supply cord is not trapped or damaged.
12. WARNING: Do not locate multiple portable socket-outlets or portable power supplies at the rear of the appliance.

B.FUNCTION INTRODUCTION

1. This series model can satisfy the need of tea & coffee and making drinking. It must be used indoor only.
2. With adoption of distinctive thermal isolation technology, this machine can minimize thermal exchange between hot & cold water.
3. Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.

C.PART NAME




NO.	PART NAME	NO.	PART NAME
1	bottle supporter	7	tap of hot water
2	top cover	8	water collector
3	push button of normal water	9	heating switch
4	push button of hot water	10	power cord
5	front carapace	11	outlet of hot water
6	tap of normal water		

NOTE:

This machine is suitable for bottle of 3 or 5 gallons. Don't use unhealthy hard water.





D. OPERATION INSTRUCTION

1. Tear the label from the bottle.
2. Vertically insert the bottle into the bottle supporter on top of the machine . Don't plug the power cord or push the heating switch until water runs out from the tap of hot water.
3. Insert the plug to socket ,then turn on the switch . Indicators light up accordingly once the machine works.
4. Vertically pull out the bottle by two hands when the bottle is empty , then replace it with another bottle of water.
5. This appliance should work under environment of temp from 4 ~ 40 C humidity $\leq 90\%$.
6. This appliance is not suitable for installation in an area where a water jet could be used.



E. CAUTION


1. Keep this machine in place of dry and avoid direct sunshine. Rear of the machine should be no more than 75mm against from the wall. Never put the machine on paper or foam, which may cause unstable condition, Never put anything flammable beside this machine.
2. To avoid damage to the machine. Don't plug the power cord or push the red switch until water runs out from the tap of hot water.
3. In case hot water is not needed for a long time, turn off the switch accordingly to save power.
4. In case not to use this machine for a long time, turn off the switch, then pull the plug out from socket and drain the remaining water through draining outlet.




5. Never use organic liquid to clean the machine. Strictly prohibit using water to the splash it.



6. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.



7. Do not operate dispenser with a damaged cord, return the dispenser to the nearest authorized service facility for repair or adjustment.



F. TROUBLE SHOOTING

Please check the followings before having the machine repaired.

PROBLEMS	POSSIBLE CAUSES	ELIMINATION
no hot water	1. over consumption of hot water in short time 2. no power supply	1. just wait a moment, then hot water is available again. 2. connect plug to socket, turn on heating switch.
no water running out from taps	1. empty bottle 2. inlet of bottle supporter blocked by bottle seal	1. replace it with another one 2. clean out wasted paper & bottle seal, install bottle again.
leakage from bottle supporter	broken bottle	replace it with a new bottle
noisy operation	not placid installation	place the machine on placid & solid surface

G. CLEANING

To avoid accident, cut off the power supply before operation according to the following instruction.

1. The machine had been disinfected before departed from factory.
Cleaning the dispenser prior to installing a full bottle of water for the first time.

2. **Cleaning and draining instruction:**

- ❶ Before cleaning, make sure the power switch in the *O(off)* position and unplug the water dispenser.
- ❷ Vertically insert the bottle into the supporter on top of the machine.
- ❸ Turn on all the taps in turn for 3 minutes after the water outflow, which completes the internal pipeline flushing.
- ❹ Removed the water bottle from the dispenser.
- ❺ Place a large bucket beneath the drain outlet. Remove the drain cover and allow water to drain.
- ❻ After draining, replace the drain cover and you can use the machine.

Attention: The dispenser heats water to a temperature of approximately 85°C. It can cause severe burns. Please operation it carefully.

3. **Sanitizing:**

The machine should be disinfected with the disinfectant separately bought from drugstore or marketplace according to the instruction manual of the disinfectant and then clean it with water (see **cleaning and draining instruction**). Generally this should be done every three months.

4. **To Remove Mineral Deposits:**

Mix 4 liters water with 200g citric acid crystals, inject into the machine and make sure the water can flow out of the hot water tap. Switch on the power and heat it about 10 minutes. 30 minutes later, drain off the liquor and clean it with water for two or three times. Generally this should be done every six months. Never disassemble this machine by yourself to avoid danger from damaged machine.

5. Never disassemble this machine by yourself to avoid danger from damaging machine.

H. MACHINE INSTALLATION


For RM/561 model

▲ CAUTION

To prevent accidental tip hazard, dispenser must be securely anchored to wall as shown.

1. Place dispenser upright.
2. Locate dispenser on a hard and level surface in a cool shaded location near a grounded wall outlet.
Notice: Do NOT plug in power cord yet.
3. Position dispenser so the back is at least 4 inches from wall and there are at least 4 inches of clearance on both sides.
4. Install bracket to prevent accidental tip over:

- Clip bracket onto back right corner of dispenser as shown in illustration.
- Install plastic anchor directly into sheet rock using a Philips screwdriver. DO NOT drill hole into sheet rock first when using this anchor.
- Secure by installing screw through bracket and into the anchor.



Note

Remove screw to free dispenser for cleaning or relocating.